

ADDITIONAL KIT



Use this kit in conjunction with the # 433 437 Slide hammer and flange to create distance between the flange and the hub if the flange does not sit flat.

433 435 Additional kit